

4 PERSON PICNIC BASKET/HAMPER SET

- User Guide

www.VonShef.com

1. **STAINLESS STEEL KNIVES/FORKS/SPOONS** (x4).
2. **7" DINNER PLATES** (x4).
3. **PLASTIC WINE GLASSES** (x4).
4. **COTTON NAPKINS** (x4).
5. **SALT & PEPPER SHAKERS** (x2).
6. **BOTTLE OPENER WITH CORKSCREW** (x1).
7. **PICNIC BLANKET** (x1).



WARNINGS & PRECAUTIONS

FAILURE TO FOLLOW THESE INSTRUCTIONS WILL INVALIDATE ANY GUARANTEE.

This 4 Person Picnic Basket/Hamper Set is not a toy and is not suitable for children. Children should be supervised at all times around this Hamper Set.

This Hamper Set contains sharp, bladed or pointed objects and small parts and components which pose a laceration or choking hazard to children and animals. Keep these parts clear from children and pets.

The knives and corkscrew are sharp and should always be handled with extreme care and caution. Use the handles at all times.

WARNING! Knives and utensils contain sharp edges which pose a serious risk of injury if used incorrectly. Knives and utensils are not to be used by persons under the age of 18.

Supervision should be given and due care taken when using any sharp implements around children, pets and vulnerable adults. Always store out of reach.

Never run with a knife or handle more than one knife at a time. Grasp each item firmly by the handle at all times.

Never leave knives or sharp objects unattended whilst in use or loose on any surface.

Never attempt to catch a falling knife or sharp object.

WARNING! Your Hamper Set is not suitable for carrying hot foods or drinks unless suitably contained within an insulating flask or container.

WARNING! Keep the Picnic Blanket away from heat sources such as BBQs and pit fires.

Ensure all straps are secured before attempting to carry the Hamper.

Do not use any broken or damaged items. Serious risk of accident or injury is present when using defective items.

CLEANING & MAINTENANCE

Before using your Hamper Set for the first time, remove all packaging, stickers and labels from the product and retain for future reference or store for future use.

Hand-wash all cutlery and tableware items thoroughly in warm water with a mild detergent and dry thoroughly immediately afterwards. Do not leave to air-dry.

CAUTION: Do not use harsh or abrasive chemical cleaners or detergents with your cutlery and tableware items as these may cause damage or deteriorate the quality. Use of metal scouring pads or similar is not recommended as these may damage the finish.

NOTE: The cutlery of your Hamper Set is dishwasher-safe. However, due to the heat and stress generated by dishwashers, hand-washing is recommended in order to prevent tarnishing. Be advised that stainless steel exterior finishes and fixings may become dull due to the abrasive nature of some dishwasher detergents. These effects are not covered under guarantee.

After each use, thoroughly clean and dry your cutlery and tableware items. The fabric lining can be vacuumed clean to remove crumbs or spot cleaned to remove stains.

CAUTION: The Picnic Blanket is not machine-washable.

CUSTOMER SERVICES

If you are having difficulty using your product and require support, please contact hello@domu.co.uk

DISPOSAL INFORMATION

Please recycle where facilities exist. Check with your local authority for recycling advice.

WARRANTY

To register your product and find out if you qualify for a free extended warranty, go to:

www.VonShef.com/warranty

Please retain a proof of purchase receipt or statement as proof of the purchase date.

The warranty only applies if the product is used solely in the manner indicated in this User Guide, and all instructions have been followed accurately. Any abuse of the product or the manner in which it is used will invalidate the warranty.

Returned goods will not be accepted unless re-packaged in its original colour box and accompanied by a relevant and completed returns form. This does not affect your statutory rights.

No rights are given under this warranty to a person acquiring this product second-hand or for commercial or communal use.

COPYRIGHT

All material in this instruction manual are copyrighted by DOMU Brands Ltd.

Any unauthorised use may violate worldwide copyright, trademark, and other laws.

Thank you for purchasing the 4 Person Picnic Basket/Hamper Set.
VonShef® is a registered trademark of DOMU Brands Ltd
Made in China for DOMU Brands Ltd M24 2RW.